

1. Power on TV.
2. Press and HOLD [ON/OFF] and [MUTE] buttons together until the indicator light illuminates (3 seconds).
3. Press and RELEASE the [CH+] button, repeatedly, until the TV turns on. (Tek Pal contains more than 200 codes)
4. Press and release the [MUTE] button immediately after the TV turns on to complete set-- up.
5. Power the TV on using [ON/OFF]. Tip: If the TV does not power back on, you may have pressed [CH +] after the TV turned on. Proceed with setup again, but at step 3 use [CH-] to go backwards through the codes. Your TV should turn on with just a few presses of the [CH-] button.
6. For TV only users (no cable box or satellite receiver): Test the [Vol+/-], [CH+/-], and [On/ Off]. If any buttons do not function, proceed with set up again.

7. For cable box/satellite receiver users: Test [On/Off] and [Vol +/-]. If [On/OFF] or [Vol +/-] buttons do not function, proceed with set up again to find a better code. Then, proceed with additional set up procedures below.

### **Additional Set up Procedures for Cable/Satellite devices**

1. Program TV first using instructions above.
2. Power on TV and Cable or Satellite device. 3. Press and HOLD [MUTE] and then the [ON/OFF] button together until the indicator light illuminates (3 seconds).
4. Press and RELEASE the [Vol+] repeatedly until the cable or satellite device turns on.
5. Press and release [MUTE] immediately after the cable or satellite device turns on.
6. Power the device back on manually or using your old remote.

7. Press and HOLD [CH-] and then [ON/OFF] buttons together until the indicator light blinks three times. This step will configure the Tek-Pal to change channels on the cable or satellite device.

8. If the channels do not change, proceed with setup of cable or satellite device again.

Tip: If channels do not change, you may have pressed [Vol+] after the device turned on. Proceed with setup again, but at step 3 use [Vol-] to go backwards through the codes. Your device should turn on with just a few presses of the [Vol--] button.

9. To enable Master Power: First, power on both the TV and cable or satellite device. Press and HOLD [MUTE] and then [On/Off] together (3 seconds) until the indicator light illuminates. Press and RELEASE [On/Off] three times. Press and release [MUTE].